

FLEXIBLE BRAKE HOSES- FRONT

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
810-110 FR BRAKE HOSE	2	1935-38 all PLYMOUTH	1935-38 all DODGE	1935-38 all DESOTO	1935-38 6-cylinder
810-042 FR BRAKE HOSE					1935-38 8-cylinder
810-045 FR BRAKE HOSE	2	1939-42 all PLYMOUTH	1939-42 all DODGE	1939-42 all DESOTO	1939-42 6-cylinder
810-043 FR BRAKE HOSE	2	1955-56 all PLYMOUTH	1949-52 exc Wayfarer 1953-54 exc 10" brakes 1955-56 all 1955-56	1949-56 all DESOTO	1946-48 8-cylinder 1949-52 all CHRYSLER 1953-55 exc CROWN IMP 1956 all CHRYSLER all IMPERIAL
810-144 FR BRAKE HOSE	2	1946-54 all PLYMOUTH	1946-48 all DODGE 1949-52 Wayfarer 1953-54 w/10" brakes	1946-48 all DESOTO	1946-48 6-cylinder
810-047 FR BRAKE HOSE	2				1953-55 CROWN IMPERIAL
810-180 FR BRAKE HOSE	2	1957-59 all PLYMOUTH	1957-59 all DODGE	1957-59 FIRESWEEP	1958-59 Windsor
810-041 FR BRAKE HOSE	2			1957-59 exc FIRESWEEP	1957 all CHRYSLER all IMPERIAL 1958-59 exc WINDSOR