

SPEEDOMETER CABLES

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
808-182 Cable/Housing	1	1935-36 all PLYMOUTH	1935-36 all DODGE	1935-36 Airstream w/o overdrive	1936 Airstream w/o overdrive
808-183 Cable/Housing	1	1937-38 all PLYMOUTH	1937-38 all DODGE	1936 Airstream w/ overdrive 1937-38 w/o overdrive	1935 Airstream 1936 Airstream w/ overdrive 1937-38 C14, 15, 16, 18, 19 w/o overdrive
808-184 Cable/Housing	1	1939 all PLYMOUTH	1939 all DODGE	1937-38 w/ overdrive	1937-38 C14, 15, 16, 18, 19 w/ overdrive 1939 all CHRYSLER
808-185 Cable/Housing	1	1940-42 all PLYMOUTH	1940-42 w/o overdrive	1940 w/o overdrive	1940 all CHRYSLER
808-186 Cable/Housing	1		1940-42 w/ overdrive	1941-42 all DESOTO	1941-42 all CHRYSLER
808-187 Cable/Housing	1	1946-48 all PLYMOUTH	1946-48 all DODGE	1946-48 all DESOTO	1946-49 all CHRYSLER
808-188 Cable/Housing	1	1949 all PLYMOUTH	1949 all DODGE	1949 all DESOTO	
808-088 Cable/Housing	1	1950-52 w/o overdrive 1953-54 w/ HY-DRIVE w/ overdrive 1955-57 w/ man trans	1950-51 all DODGE	1950-51 all DESOTO 1957 Firedome	1951-52 New Yorker Saratoga
808-085 Cable/Housing	1	1955-56 w/ Powerflite w/ overdrive 1957 w/ auto trans 1958-59 all PLYMOUTH	1952 all DODGE 1957 w/ man trans 1958-59 exc Torqueflite	1952-56 w/o overdrive 1957 Fireflite 1958 exc Firesweep	1950 all CHRYSLER all IMPERIAL 1951-52 all IMPERIAL Windsor 1953 Windsor 1954-58 all CHRYSLER all IMPERIAL
808-086 Cable/Housing	1	1952 w/ overdrive	1953-56 all DODGE 1957 w/ auto trans 1958-59 w/ Torqueflite	1952-54 w/ overdrive 1957-58 Firesweep 1959 all DESOTO	1953 New Yorker all IMPERIAL 1959 all CHRYSLER all IMPERIAL
808-175 Cable/Housing	1	1953-54 w/o overdrive w/o Hy-drive			