

FRONT SUSPENSION

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
860-014 UPPR BALLJOINT	2	1957-58	1957-58	1957-58	1958
860-015 LOWR BALL JOINT	2	all PLYMOUTH	all DODGE	Firesweep	Windsor
860-011 U CTRL ARM BUSH	4				
860-012 L CTRL ARM BUSH	2				
960-001 STRUT BUSHG KIT	2				
860-018 U CTRL ARM BUMP	2				
860-019 L CTRL ARM BUMP	2				
860-024 L CNTL ARM BUMP	2				
825-022 TOR BAR RETAINR	2				
860-037 SW BAR RET BUSH	2				
860-022 SW BAR OTR BUSH	2				
860-023 SW BAR INR BUSH	2				
860-016 UPPR BALL JOINT	2			1957-58	1957
860-017 LOWR BALL JOINT	2			exc Firesweep	all CHRYSLER all IMPERIAL
860-021 U CTRL ARM BUSH	4				1958 exc Windsor
860-013 L CTRL ARM BUSH	2				
960-001 STRUT BUSHG KIT	2				
860-018 U CTRL ARM BUMP	2				
860-019 L CTRL ARM BUMP	2				
1957					
860-024 L CTRL ARM BUSH	2				
1958					
825-023 TOR BAR RETAINR	2				
860-037 SW BAR RET BUSH	2				
860-022 SW BAR OTR BUSH	2				
860-023 SW BAR INR BUSH	2				
860-014 UPPR BALL JOINT	2	1959	1959	1959	1959
860-015 LOWR BALL JOINT	2	all PLYMOUTH	all DODGE	Firesweep	Windsor
860-020 U CTRL ARM BUSH	4				
860-012 L CTRL ARM BUSH	2				
960-001 STRUT BUSHG KIT	2				
860-039 U CTRL ARM BUMP	2				
860-024 L CTRL ARM BUMP	2				
825-023 TOR BAR RETAINR	2				
860-037 SW BAR RET BUSH	2				
860-022 SW BAR OTR BUSH	2				
860-023 SW BAR INR BUSH	2				
806-003 TORSN BAR SEAL	2				