

## PARKING BRAKE CABLES

ATLAS P/N	QTY REQ	A-BODY	B-BODY	E-BODY	C/Y-BODY
808-130 FRONT CABLE	1	1960			
808-131 REAR CABLE	1	VALIANT			
808-094 BRAKE CABLE	1		1960-61 w/ auto trans		1960-61 exc w/ Auto-Pilot exc IMPERIAL
808-132 FRONT CABLE	1	1961-62			
808-134 INTERMEDIATE CABLE	1	all A-BODY			
808-133 REAR CABLE	2				
808-125 BRAKE CABLE	1				1960-62 all IMPERIAL
808-129 BRAKE CABLE	1				1960-61 w/ Auto-Pilot exc IMPERIAL
808-135 FRONT CABLE	1		1962		
808-136 INTERMEDIATE CABLE	1		hand operated		
808-137 REAR CABLE	2				
808-139 FRONT CABLE	1		1962		
808-136 INTERMEDIATE CABLE	1		foot operated		
808-137 REAR CABLE	2				
808-139 BRAKE CABLE	1				1962 exc IMPERIAL
808-013 FRONT CABLE	1	1963-66	1964		
808-097 INTERMEDIATE CABLE	1	all A-BODY	hand operated		
808-054 REAR CABLE	2				
808-144 FRONT CABLE	1		1963		
808-176 INTERMEDIATE CABLE	1		hand operated		
808-054 REAR CABLE	2				
808-143 FRONT CABLE	1		1963-64		
808-176 INTERMEDIATE CABLE	1		foot operated		
808-054 REAR CABLE	2		1965 all B-BODY		
808-007 FRONT CABLE	1				1963-64 exc IMPERIAL
808-145 RH REAR CABLE	1				
808-024 LH REAR CABLE	1				
808-146 FRNT PRI CABLE	1				1963 IMPERIAL
808-147 FRNT SEC CABLE	1				
808-024 REAR CABLE	2				
808-015 FRONT CABLE	1				1965-67 CHRYSLER
808-145 RH REAR CABLE	1				
808-024 LH REAR CABLE	1				
808-014 FRONT CABLE	1				1965-67 FURY exc Wagon
808-145 RH REAR CABLE	1				
808-024 LH REAR CABLE	1				
808-017 FRONT CABLE	1				1965-67 MONACO, POLARA, 880 exc Wagon
808-145 RH REAR CABLE	1				
808-024 LH REAR CABLE	1				
808-149 FRNT PRI CABLE	1				1964-66 all IMPERIAL
808-148 FRNT SEC CABLE	1				
808-024 REAR CABLE	2				
808-015 FRONT CABLE	1		1966		
808-145 RH REAR CABLE	1		all B-BODY		
808-024 LH REAR CABLE	1				
808-002 FRONT CABLE	1	1967-69			
808-059 RH REAR CABLE	1	all A-BODY			
808-067 LH REAR CABLE	1				
808-016 FRONT CABLE	1		1967-69		
808-145 RH REAR CABLE	1		all B-BODY		
808-024 LH REAR CABLE	1				
808-015 FRONT CABLE	1				1967-68 all IMPERIAL
808-145 RH REAR CABLE	1				

808-024 LH REAR CABLE	1				
-----------------------	---	--	--	--	--

### PARKING BRAKE CABLES (CONT'D)

ATLAS P/N	QTY REQ	A-BODY	B-BODY	E-BODY	C/Y-BODY
808-014 FRONT CABLE	1				1968-69 FURY exc Wagon
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-017 FRONT CABLE	1				1968-69 MONACO,POLARA
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-015 FRONT CABLE	1				1969 all IMPERIAL
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-001 FRONT CABLE	1	1970 DART,VALIANT			
808-151 RH REAR CABLE	1				
808-067 LH REAR CABLE	1				
808-002 FRONT CABLE	1	1970 DART			
808-151 RH REAR CABLE	1				
808-067 LH REAR CABLE	1				
808-152 FRONT CABLE	1			1970 BARRACUDA exc 11" brakes	
808-153 RH REAR CABLE	1				
808-155 LH REAR CABLE	1				
808-152 FRONT CABLE	1			1970 BARRACUDA w/ 11" brakes	
808-154 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-005 FRONT CABLE	1			1970 CHALLENGER exc 11" brakes	
808-153 RH REAR CABLE	1				
808-155 LH REAR CABLE	1				
808-005 FRONT CABLE	1			1970 CHALLENGER w/ 11" brakes	
808-154 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-016 FRONT CABLE	1		1970 w/ 10" brakes		
808-156 RH REAR CABLE	1				
808-071 LH REAR CABLE	1				
808-016 FRONT CABLE	1		1970 w/ 11" brakes		
808-073 RH REAR CABLE	1				
808-074 LH REAR CABLE	1				
808-007 FRONT CABLE	1				1970 MONACO,POLARA
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-008 FRONT CABLE	1				1970 FURY exc Wagon
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				
808-159 FRONT CABLE	1	1971 DART, VALIANT 8-cylinder			
808-158 RH REAR CABLE	1				
808-067 LH REAR CABLE	1				
808-157 FRONT CABLE	1	1971 DEMON, DUSTER 8-cylinder			
808-158 RH REAR CABLE	1				
808-067 LH REAR CABLE	1				
808-003 FRONT CABLE	1				1970 all CHRYSLER all IMPERIAL
808-031 RH REAR CABLE	1				
808-150 LH REAR CABLE	1				