

FRONT BRAKE DRUM/HUBS

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
862-317 RH DRUM/HUB	2	1936-39 all PLYMOUTH			
862-313 LH DRUM/HUB	1		1939-42		
862-314 LH DRUM/HUB	1		all DODGE		
862-317 RH DRUM/HUB		1940-42			
862-318 LH DRUM/HUB		all PLYMOUTH			
862-341 RH DRUM/HUB	1	1946-48			
862-342 LH DRUM/HUB	1	all PLYMOUTH			
862-345 RH DRUM/HUB	1		1946-48		
862-346 LH DRUM/HUB	1		all DODGE		
862-343 RH DRUM/HUB	1			1946-48	
862-344 LH DRUM/HUB	1			all DESOTO	
862-347 RH DRUM/HUB	1				1946-48
862-348 LH DRUM/HUB	1				6-cyl exc LONG WB
862-321 RH DRUM/HUB	1			1949	
862-322 LH DRUM/HUB	1			exc LONG WB`	
962-055 RH DRUM/HUB	1			1949-55	1949-52
962-056 LH DRUM/HUB	1			EST WAGON	NEW YORKER IMPERIAL EST WAGON
962-007 RH DRUM/HUB	1	1949-50			1953-55
962-008 LH DRUM/HUB	1	all PLYMOUTH			all IMPERIAL all WAGON
862-351 RH DRUM/HUB	1		1949		
862-352 LH DRUM/HUB	1		all WAYFARER		
962-045 RH DRUM/HUB	1		1949-52		
962-046 LH DRUM/HUB	1		exc WAYFARER 1953-54 exc D47, D52		
862-349 RH DRUM/HUB	1			1950-52	
862-350 LH DRUM/HUB	1			6-cyl exc LONG WB	
862-253 RH DRUM/HUB	1				1950
862-254 LH DRUM/HUB	1				6-cyl 1951-52 SARATOG, WINDS exc WAGON
962-043 RH DRUM/HUB	1	1951-54			1953-Early 1955
962-044 LH DRUM/HUB	1	all PLYMOUTH 1955-56 w/ 10" brakes			exc IMPERIAL
962-028 RH DRUM/HUB	1		1955-56		
962-029 LH DRUM HUB	1		w/ 11" brakes		
862-323 RH DRUM/HUB	1	1955-56			
862-324 LH DRUM/HUB	1	w/ 11" brakes			

FRONT BRAKE DRUM/HUBS (CONT'D)

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
862-335 RH DRUM/HUB 862-324 LH DRUM/HUB	1 1			1952 8-cyl 1953-54 exc WAGON 1955 (early) exc WAGON	
962-051 RH DRUM/HUB 962-052 LH DRUM/HUB	1 1			1956 exc WAGON	
862-353 RH DRUM/HUB 862-354 LH DRUM/HUB	1 1				1956 exc IMPERIAL exc wagon
962-016 RH DRUM/HUB 962-017 LH DRUM/HUB	1 1				1957-59 all IMPERIAL
862-330 RH DRUM/HUB 862-331 LH DRUM/HUB	1 1	1957-59 w/ 11" brakes			
962-012 RH DRUM/HUB 962-013 LH DRUM/HUB	1 1		1957-58 w/ 11" brakes	1957-58 all FIRESWEEP	1958 all WINDSOR
962-053 RH DRUM/HUB 962-054 LH DRUM/HUB	1 1	1958 w/ 12" brakes	1957-58 w/ 12" brakes	1957-58 w/ 12" brakes	1957-58 w/ 12" brakes exc IMPERIAL
862-305 RH DRUM/HUB 862-306 LH DRUM/HUB	1 1		1959 w/ 11" brakes	1959 w/ 11" brakes	1959 w/ 11" brakes
962-020 RH DRUM/HUB 962-021 LH DRUM/HUB	1 1	1959 w/ 12" brakes	1959 w/ 12" brakes	1959 w/ 12" brakes	1959 w/ 12" brakes exc IMPERIAL