



**TEMPERATURE GUAGE SENDERS  
TEMPERATURE WARNING LIGHT SWITCHES**

<b>ATLAS P/N</b>	<b>QTY REQ</b>	<b>PLYMOUTH</b>	<b>DODGE</b>	<b>DESOTO</b>	<b>CHRYSLER/ IMPERIAL</b>
803-003 Gauge Sender	1	1955-56 all PLYMOUTH	1955-56 all DODGE	1955-56 all DESOTO	1955-56 all CHRYSLER all IMPERIAL
803-004 Gauge Sender	1	1957-59 all PLYMOUTH	1957-58 all DODGE	1957-59 all DESOTO	1957-59 all CHRYSLER all IMPERIAL
803-005 Gauge Sender	1	1960-63 all PLYMOUTH	1959-63 all DODGE	1960-61 all DESOTO	1960-63 all CHRYSLER all IMPERIAL
803-006 Gauge Sender	1	1964-74 all PLYMOUTH	1964-74 all DODGE		1964-74 all CHRYSLER all IMPERIAL
838-007 Warning Lite SW	1				1967-73 all CHRYSLER all IMPERIAL



$\frac{1}{4}$ " Pipe Thread

803-003



$\frac{1}{4}$ " Pipe Thread

803-004

**OIL PRESSURE GUAGE SENDERS  
OIL PRESSURE WARNING LIGHT SWITCHES**

<b>ATLAS P/N</b>	<b>QTY REQ</b>	<b>PLYMOUTH</b>	<b>DODGE</b>	<b>DESOTO</b>	<b>CHRYSLER/ IMPERIAL</b>
838-129 Warning Lite SW	1	1956-59 all PLYMOUTH	1959 all DODGE	1959 all DESOTO	

