

IGNITION & STARTER SWITCHES

| ATLAS P/N | QTY REQ | PLYMOUTH | DODGE | DESOTO | CHRYSLER/ IMPERIAL |
|------------------------------|---------|---------------------|---------------------|---------------------|-----------------------|
| 838-294 Ign Switch & Cable | 1 | 1937-38 | | 1938 | |
| 818-025 Lock Cyl & Keys | 1 | all PLYMOUTH | | all DESOTO | |
| 838-020 Floor Starter Switch | 1 | | | | |
| 838-295 Ign Switch & Cable | 1 | | 1937-38 | 1937 | 1937 |
| 818-025 Lock Cyl & Keys | 1 | | all DODGE | all DESOTO | exc C17 |
| 838-020 Floor Starter Switch | 1 | | | | 1938 |
| 838-021 Dash Starter Switch | 1 | | | | all CHRYSLER |
| 838-291 Ign Switch & Cable | 1 | 1939 | 1939 | 1939 | 1939 |
| 818-025 Lock Cyl & Keys | 1 | all PLYMOUTH | all DODGE | all DESOTO | all CHRYSLER |
| 838-020 Floor Starter Switch | 1 | 1942 | 1942 | 1941-42 | 1941 |
| 838-021 Dash Starter Switch | 1 | all PLYMOUTH | all DODGE | exc Underdrive | all CHRYSLER |
| | | | | | 1942 |
| | | | | | C34 |
| 838-292 Ign Switch & Cable | 1 | 1940-41 | 1940-41 | 1940 | |
| 818-025 Lock Cyl & Keys | 1 | all PLYMOUTH | all DODGE | all DESOTO | |
| 838-020 Floor Starter Switch | 1 | | | | |
| 838-021 Dash Starter Switch | 1 | | | | |
| 838-293 Ign Switch & Cable | 1 | | | 1941-42 | 1942 |
| 818-025 Lock Cyl & Keys | 1 | | | w/ Underdrive | C36, C37 |
| 838-021 Dash Starter Switch | 1 | | | | |
| 838-290 Ign Switch | 1 | 1946-48 | 1946-48 | 1946-48 | 1946-48 |
| 818-025 Lock Cyl & Keys | 1 | exc Hurd style | exc Hurd style | exc Hurd style | exc Hurd style |
| 838-021 Dash Starter Switch | 1 | | | | |
| 838-420 Ign Switch | 1 | 1946-48 | 1946-48 | 1946-48 | 1946-48 |
| 818-149 Lock Cyl & Keys | 1 | w/ Hurd style locks | w/ Hurd style locks | w/ Hurd style locks | w/ Hurd s tyle locks |
| 838-021 Dash Starter Switch | 1 | | | | |
| 838-019 Ign/Starter Switch | 1 | 1949-57 | 1949-56 | 1949-57 | 1949-56 |
| 818-025 Lock Cyl & Keys | 1 | all PLYMOUTH | all DODGE | all DESOTO | all CHRYSLER |
| | | | 1957-58 | | |
| | | | w/o Torqueflite | | |
| 838-023 Ign Switch | 1 | | 1957 | | 1957-58 |
| 818-025 Lock Cyl & Keys | 1 | | w/ Torqueflite | | all Chrysler |
| | | | 1958 | | all IMPERIAL |
| | | | LD1 | | |
| | | | w/ Torqueflite | | |
| 838-024 Ign Switch | 1 | | 1958 | | |
| 818-025 Lock Cyl & Keys | 1 | | LD2, LD3 | | |
| | | | w/ Torqueflite | | |
| 838-022 Ign/Starter Switch | 1 | 1958-59 | 1959 | 1958-59 | 1959 |
| 818-025 Lock Cyl & Keys | 1 | all PLYMOUTH | all DODGE | all DESOTO | all CHRYSLER |
| | | | | | all IMPERIAL |