

STARTER RELAYS/SOLENOIDS

ATLAS P/N	QTY REQ	A-BODY	B-BODY	E-BODY	C/Y-BODY
823-024 Starter Solenoid	1	1960 w/ auto trans			
823-025 Starter Solenoid	1	1960 w/ manual trans			
823-017 Starter Solenoid	1		1960 w/ manual trans		
823-062 Starter Relay	1				1960 exc WINDSOR exc DESOTO
823-046 Starter Relay	1				1960 DESOTO, WINDSOR
823-019 Starter Solenoid	1		1960 w/ manual trans		
823-023 Starter Solenoid	1	1961 w/ auto trans			
823-029 Starter Solenoid	1	1961 w/ manual trans			
823-027 Starter Relay	1	1962-65 w/ auto trans	1961-65 w/ auto trans		1961-64 w/ auto trans
823-026 Starter Solenoid	1				1965 all IMPERIAL
823-028 Starter Relay	1	1962-65 w/ manual trans	1961-65 w/ manual trans		1961-64 w/ man
823-030 Starter Solenoid	1				
823-016 Starter Relay	1	1966-69 w/ auto trans 1970-74 all A-BODY	1966-69 w/ auto trans 1970-74 all B-BODY	1970-74 all E-BODY	1965-66 w/ auto trans 1974 all C/Y-BODY
823-014 Starter Relay	1	1966-69 w/ man trans	1966-69 w/ man trans		1965-66 w/ man trans
823-015 Starter Relay	1				1967-68 w/ auto trans
823-018 Starter Relay	1				1969 w/ auto trans 1970-73 all C/Y-BODY
823-055 Starter Relay	1				1969 w/ man trans