

**FRONT WHEEL BEARINGS
FRONT WHEEL GREASE SEALS**

ATLAS P/N	QTY REQ	A-BODY	B-BODY	E-BODY	C/Y-BODY
861-001 INNER SET	2		1960-61 all B-BODY		1960-62 exc IMPERIAL
861-002 OUTER SET	2				
806-016 GREASE SEAL	2				
925-009 NUT KIT	2				
824-001 DUST CAP	2				
861-003 INNER SET	2				1960-62 IMPERIAL
861-004 OUTER SET	2				
806-018 GREASE SEAL	2				
861-005 INNER SET	2	1960-63 all A-BODY			
861-006 OUTER SET	2	1964-72 w/9" brakes			
806-022 GREASE SEAL	2				
861-001 INNER SET	2		1962-66 all B-BODY	1970-72 w/ 11" brakes	1963-72 exc IMPERIAL
861-002 OUTER SET	2		1967-72 w/ 11" drum brakes		
806-021 GREASE SEAL	2				
925-009 NUT KIT	2				
824-001 DUST CAP	2				
861-001 INNER SET	2	1965-72 w/ 10" brakes	1967-72 exc 11" brakes	1970-72 exc 11" brakes	
861-002 OUTER SET	2	w/ disc brakes			
806-016 GREASE SEAL	2				
925-009 NUT KIT	2				
824-001 DUST CAP	2				
861-003 INNER SET	2				1963-73 IMPERIAL
861-004 OUTER SET	2				
806-018 GREASE SEAL	2				
861-368 INNER SET	2	1973-74 w/ 10" drum brakes			
861-002 OUTER SET	2				
806-892 GREASE SEAL	2				
925-008 NUT KIT	2				
824-001 DUST CAP	2				
861-368 INNER SET	2	1973-74 w/ disc brakes	1973-74 all B-Body	1973-74 all E-Body	
861-002 OUTER SET	2				
806-893 GREASE SEAL	2				
925-008 NUT KIT	2				
824-001 DUST CAP	2				